

DMX Channel Index

impression[&]
X4S



from software version: 1.16
(Instruction version: 1.1)



e-mail: service@glp.de
Internet: <http://www.glp.de>

DMX Channel Selection (DMX Protocol)

Normal-Mode 18 DMX channels

Channel	Function	Time and Value	DMX	HEX	%
1) PAN-coarse			0..255	00..FF	0..100
2) PAN-fine			0..255	00..FF	0..100
3) Tilt-coarse			0..255	00..FF	0..100
4) Tilt-fine			0..255	00..FF	0..100
5) Color (fixed)	Colors adjustable via RGBW		0..7	00..07	0..2.5
	Color 01 - Red ¹⁾		8..15	08..0F	3..5.5
	Color 02 - Amber ¹⁾		16..23	10..17	6..8.5
	Color 03 - Warm Yellow ¹⁾		24..31	18..1F	9..12.5
	Color 04 - Yellow ¹⁾		32..39	20..27	13..15.5
	Color 05 - Green ¹⁾		40..47	28..2F	16..18.5
	Color 06 - Turquoise ¹⁾		48..55	30..37	19..21.5
	Color 07 - Cyan ¹⁾		56..63	38..3F	22..24.5
	Color 08 - Blue ¹⁾		64..71	40..47	25..27.5
	Color 09 - Lavender ¹⁾		72..79	48..4F	28..30.5
	Color 10 - Malve (Mauve) ¹⁾		80..87	50..5F	31..34.5
	Color 11 - Magenta ¹⁾		88..95	58..5F	35..37.5
	Color 12 - Pink ¹⁾		96..103	60..67	38..40.5
	White - CTO	3200K	104..111	68..6F	41..43.5
	White	5600K	112..119	70..7F	44..46.5
	White - CTB	7200K	120..127	78..7F	47..49.5
Rainbow Effect Stop ²⁾		128	80	50	
Rainbow Effect ³⁾	slow - fast	129..223	81..DF	51..88	
Random colors	slow - fast	224..255	E0..FF	89..100	
6) Red	Color mixing system - Red	0 - 100%	0..255	00..FF	0..100
7) Green	Color mixing system - Green	0 - 100%	0..255	00..FF	0..100
8) Blue	Color mixing system - Blue	0 - 100%	0..255	00..FF	0..100
9) White	Color mixing system - White	0 - 100%	0..255	00..FF	0..100
10) Shutter	Shutter closed		0..15	00..0F	0..5.5
	Shutter pulse random	slow – fast	16..47	10..2F	6..18.5
	Up-dimming then Shutter closing (random patterns)	slow – fast	48..79	30..4F	19..31
	Shutter open then down-dimming (random patterns)	slow – fast	80..111	50..6F	32..43
	Up-dimming then down-dimming (random patterns)	slow – fast	112..143	70..8F	44..56
	Strobe effect pause	5s - 0.1s	160..199	A0..C7	63..77
	Strobe effect slow - fast	1 Hz - 10 Hz	200..239	C8..EF	78..94
	Shutter open		240..255	F0..FF	95..100
11) Dimmer	Dimmer	0 - 100%	0..255	0..FF	0..100
12) CTO	No CTO		0..7	0..07	0..2.5
	Continuous color temperature correction	Applicable for ALL colors	8..255	08..FF	3..100
13) Special	Pattern Block 1 → channel 17		0..3	00..03	0..1
	Change PWM frequency		100..200	64..C8	40..78
	RESET		250..255	FA..FF	98..100
14) Movement macros	No macros		0	00	0
	Movement	Size	Phase	Use "Speed" to adjust	
	PAN	1	0°	01..01	01..01

Channel	Function	Time and Value	DMX	HEX	%
	1	90°	02..03	02..03	1.0
	1	180°	04..05	04..05	1.7
	1	270°	06..07	06..07	2.5
	PAN	2	0°	08..09	3.3
		2	90°	10..11	4.1
		2	180°	12..13	4.9
		2	270°	14..15	5.7
	PAN	3	0°	16..17	6.5
		3	90°	18..19	7.3
		3	180°	20..21	8.0
		3	270°	22..23	8.8
	PAN	4	0°	24..25	9.6
		4	90°	26..27	10.4
		4	180°	28..29	11.2
		4	270°	30..31	12
	TILT	size / phase see PAN	32..63	20..3F	13..25
	PAN / TILT	size / phase see PAN	64..95	40..5F	26..37
	PAN / TILT (inverse)	size / phase see PAN	96..127	60..7F	38..50
	Circle	size / phase see PAN	128..159	80..9F	51..62
	Circle (inverse)	size / phase see PAN	160..191	A0..BF	63..75
	Lying eight	size / phase see PAN	192..223	C0..DF	76..87
	Random movement	size / phase see PAN	224..255	E0..FF	88..100
15) Speed	Pan/Tilt movement speed from controller		0..1	00..01	0..0.5
Pan/Tilt	Pan/Tilt, slow – fast Use this channel also for the speed of the movements (channel 14).		02..255	02..FF	1..100
16) Zoom	Wide - narrow (spot)		0...255	00...FF	0...100
17) Pattern	No pattern		0..2	00..02	0..1
	Pre-defined patterns		03..253	03..FD	2..99
	Activates direct access to LED Pattern		254..255	FE..FF	100
18) Pattern Byte 1	Direct access to Pattern of LED 1..7		0...255	00...FF	0...100

Compress-Mode 14 DMX channels

Channel	Function	Time and Value	DMX	HEX	%
1) PAN-coarse			0..255	00..FF	0..100
2) PAN-fine			0..255	00..FF	0..100
3) Tilt-coarse			0..255	00..FF	0..100
4) Tilt-fine			0..255	00..FF	0..100
5) Color (fixed)	Colors adjustable via RGBW		0..7	00..07	0..2.5
	Color 01 - Red ¹⁾		8..15	08..0F	3..5.5
	Color 02 - Amber ¹⁾		16..23	10..17	6..8.5
	Color 03 - Warm Yellow ¹⁾		24..31	18..1F	9..12.5
	Color 04 - Yellow ¹⁾		32..39	20..27	13..15.5
	Color 05 - Green ¹⁾		40..47	28..2F	16..18.5
	Color 06 - Turquoise ¹⁾		48..55	30..37	19..21.5
	Color 07 - Cyan ¹⁾		56..63	38..3F	22..24.5
	Color 08 - Blue ¹⁾		64..71	40..47	25..27.5
	Color 09 - Lavender ¹⁾		72..79	48..4F	28..30.5

Channel	Function	Time and Value	DMX	HEX	%
	Color 10 - Malve (Mauve) ¹⁾		80..87	50..57	31..34.5
	Color 11 - Magenta ¹⁾		88..95	58..5F	35..37.5
	Color 12 - Pink ¹⁾		96..103	60..67	38..40.5
	White - CTO	Color temperature 3200K	104..111	68..6F	41..43.5
	White	Color temperature 5600K	112..119	70..77	44..46.5
	White - CTB	Color temperature 7200K	120..127	78..7F	47..49.5
	Rainbow Effect Stop ²⁾		128	80	50
	Rainbow Effect ³⁾	slow - fast	129..223	81..DF	51..88
	Rainbow Effect, random colors	slow - fast	224..255	E0..FF	89..100
6) Red	Color mixing system - Red	0 - 100%	0..255	00..FF	0..100
7) Green	Color mixing system - Green	0 - 100%	0..255	00..FF	0..100
8) Blue	Color mixing system - Blue	0 - 100%	0..255	00..FF	0..100
9) White	Color mixing system - White	0 - 100%	0..255	00..FF	0..100
10) Shutter	Shutter closed		0..15	00..0F	0..5.5
	Random Pulse effect	slow - fast	16..47	10..2F	6..18.5
	Up-dimming then Shutter closing (random patterns)	slow - fast	48..79	30..4F	19..31.5
	Shutter open then down-dimming (random patterns)	slow - fast	80..111	50..6F	32..43
	Up-dimming then down-dimming (random patterns)	slow - fast	112..143	70..8F	44..56
	Strobe effect pause	5s .. 1s	144..199	A0..C7	57..77
	Strobe effect, slow - fast	1 Hz .. 10 Hz	200..239	C8..EF	78..94
	Shutter open		240...249	F0..F9	95..97.5
	Shutter open		251..255	FB..FF	99..100
11) Dimmer	Dimmer	0 - 100%	0..255	0..FF	0..100
12) Zoom	Wide - narrow (spot)		0...255	00...FF	0...100
13) Special	Pattern Block 1 → channel 14		0..3	00..03	0..1
	Change PWM frequency		100..200	64..C8	40..78
	RESET		250..255	FA..FF	98..100
14) Pattern	No pattern		0..2	00..02	0..1
	Pre-defined patterns		03..253	03..FD	2..99

High Resolution (Extended) -Mode 19 DMX Channels

Channel	Function	Time and Value	DMX	HEX	%
1) PAN-coarse			0..255	00..FF	0..100
2) PAN-fine			0..255	00..FF	0..100
3) Tilt-coarse			0..255	00..FF	0..100
4) Tilt-fine			0..255	00..FF	0..100
5) Red-coarse	Color mixing system – Red	0 - 100%	0..255	00..FF	0..100
6) Red-fine	Color mixing system – Red-Low		0..255	00..FF	0..100
7) Green-coarse	Color mixing system – Green	0 - 100%	0..255	00..FF	0..100
8) Green-fine	Color mixing system – Green-Low		0..255	00..FF	0..100

Channel	Function	Time and Value	DMX	HEX	%
9) Blue-coarse	Color mixing system – Blue	0 - 100%	0..255	00..FF	0..100
10) Blue-fine	Color mixing system – Blue-Low		0..255	00..FF	0..100
11) White-coarse	Color mixing system – White	0 - 100%	0..255	00..FF	0..100
12) White-fine	Color mixing system – White-Low		0..255	00..FF	0..100
13) Shutter	Shutter closed		0..15	00..0F	0..5.5
	Random Pulse effect	slow - fast	16..47	10..2F	6..18.5
	Up-dimming then Shutter closing (random patterns)	slow - fast	48..79	30..4F	19..31.5
	Shutter open then down-dimming (random patterns)	slow - fast	80..111	50..6F	32..43
	Up-dimming then down-dimming (random patterns)	slow - fast	112..143	70..8F	44..56
	Strobe effect pause	5s - 1s	144..199	A0..C7	57..77
	Strobe effect, slow - fast	1 Hz - 10 Hz	200..239	C8..EF	78..94
	Shutter open		240...249	F0..F9	95..97.5
	Shutter open		251..255	FB..FF	99..100
14) Dimmer-coarse	Dimmer	0 - 100%	0..255	0..FF	0..100
15) Dimmer-fine	Dimmer - Low		0..255	0..FF	0..100
16) Zoom	Spot - Flood		0...255	00...FF	0...100
17) Special	Pattern Block 1 → channel 18		0..3	00..03	0..1
	Change PWM frequency		100..200	64..C8	40..78
	RESET		250..255	FA..FF	98..100
18) Pattern	No pattern		0..2	00..02	0..1
	Pre-defined patterns		03..253	03..FD	2..99
	Activates direct access to LED Pattern		254..255	FE..FF	100
19) Pattern Byte 1	Direct access to Pattern of LED 1..7		0...255	00...FF	0...100

¹⁾ The predefined colors can be used as start-colors for the Rainbow effect. Please select first a desired start-color before you activate the rainbow effect. All **IMPRESSION X4S** will then start from that color and will execute the rainbow effect synchronously. Different **IMPRESSION X4S** can have different start-colors but will still execute the rainbow effect synchronously. If you choose a color different from the ones marked with ¹⁾ in the tables above the rainbow start-color will be red.

²⁾ Rainbow-effect Stop will pause this function. After resuming the rainbow-effect will be continued from the current color.

³⁾ The Rainbow-effect will run synchronously only if started from one of the predefined colors (see also ¹⁾ before).

Locking and unlocking the Control Panel

Please lock and unlock the control panel by pressing the menu keys **MODE & ENTER & UP** at the same time.

Additional Display Indications

As a default you'll find the following additional information in the first row of the LCD display:

Vxx/xx/xx/xx/x



